



- 1 - Envello Board & Batten cladding board
- 2 - Plas-Pro or Timber battens at 600mm centres
- 3 - 30mm Cladding board fixing
- 4 - Perforated Closure
- 5 - 20mm Accessories fixing
- 6 - Horizontal starter trim
- 7 - 150mm minimum
- 8 - Ground level
- 9 - Example structural timber & sheathing or masonry wall
- 10 - Breather membrane
- 11 - Example structural base

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens

**millboard**<sup>®</sup>

Live.Life.Outside.

**Drawing detail:** Bottom of cladding detail

**Drawing number:** BBH-301-001

**Date:** 16/12/2020

**Drawn By:** SH

**Scale:** NTS

**Cladding board type:**  
Envello Board & Batten

**Orientation:** Horizontal

The Millboard Company Ltd  
UK Head Office  
Castle Court  
Bodmin Road  
Coventry CV2 5DB

T: +44 24 7643 9943  
E: enquiries@millboard.co.uk  
W: millboard.co.uk

Company Registered No.06061318  
© The Millboard Company Ltd