



- 1 - Plas-Pro or Timber batten at 400mm centres
- 2 - Plas-Pro or Timber cross battens at 400mm centres
- 3 - Envello Shadow Line cladding board
- 4 - 30mm Cladding board fixing
- 5 - Durafix 35mm fixings
- 6 - Mitred joint to be glued together, PU wood glue to be used for the core and superglue for the Lastane surface
- 7 - Example structural timber & sheathing or masonry wall
- 8 - Breather membrane

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens



Cladding board type: Envello Shadow Line
Orientation: Vertical
Drawing detail: Mitred corner detail
Drawing number: SLV-142-001

Date: 16/12/2020
Drawn By: SH
Scale: NTS

The Millboard Company Ltd
 UK Head Office
 Castle Court
 Bodmin Road
 Coventry CV2 5DB

T: +44 24 7643 9943
 E: enquiries@millboard.co.uk
 W: millboard.co.uk

Company Registered No.06061318
 © The Millboard Company Ltd