



- 1 - Envello Board & Batten cladding board
- 2 - Plas-Pro or Timber battens at 600mm centres
- 3 - 30mm Cladding board fixing
- 4 - Durafix 35mm Fixing
- 5 - Perforated Closure
- 6 - 20mm Accessories fixing
- 7 - Minimum 10mm gap
- 8 - Example soffit detail
- 9 - Example structural timber & sheathing or masonry wall
- 10 - Breather membrane

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens

millboard[®]

Live.Life.Outside.

Drawing detail: Soffit junction detail

Drawing number: BBH-303-001

Date: 16/12/2020

Drawn By: SH

Scale: NTS

Cladding board type:
Envello Board & Batten

Orientation: Horizontal

The Millboard Company Ltd
UK Head Office
Castle Court
Bodmin Road
Coventry CV2 5DB

T: +44 24 7643 9943
E: enquiries@millboard.co.uk
W: millboard.co.uk

Company Registered No.06061318
© The Millboard Company Ltd