



- 1 - 30mm Cladding board fixing
- 2 - Plas-Pro or Timber battens at 600mm centres
- 3 - Envello Board & Batten cladding board
- 4 - Junction between cladding boards and Fascia boards to be sealed with silicone, the back edge of the fascia will need to be finished with touch-up coating
- 5 - Durafix 35mm fixing
- 6 - Junction between back of fascia boards and window to be sealed with silicone
- 7 - Example window/door jamb detail
- 8 - Example structural timber & sheathing or masonry wall
- 9 - Breather membrane

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens

<p>Live.Life.Outside.</p>	<p>Cladding board type: Envello Board & Batten</p> <p>Orientation: Horizontal</p> <p>Drawing detail: Window/Door jamb junction with Fascia boards - butt joint</p> <p>Drawing number: BBH-323-001</p>	<p>Date: 16/12/2020</p> <p>Drawn By: SH</p> <p>Scale: NTS</p>	<p>The Millboard Company Ltd UK Head Office Castle Court Bodmin Road Coventry CV2 5DB</p>	<p>T: +44 24 7643 9943 E: enquiries@millboard.co.uk W: millboard.co.uk</p>
				<p>Company Registered No.06061318 © The Millboard Company Ltd</p>