



- 1 - Plas-Pro or Timber batten at 400mm centres
- 2 - Plas-Pro or Timber cross battens at 600mm centres
- 3 - 30mm Cladding board fixing
- 4 - Envello Board & Batten cladding board
- 5 - Perforated Closure
- 6 - Vertical starter trim
- 7 - 20mm Accessories fixing
- 8 - 10mm minimum
- 9 - Example Decking detail
- 10 - Example structural timber & sheathing or masonry wall
- 11 - Breather membrane
- 12 - Example structural base

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens



**Cladding board type:**  
Envello Board & Batten

**Orientation:** Vertical

The Millboard Company Ltd  
UK Head Office  
Castle Court  
Bodmin Road  
Coventry CV2 5DB

T: +44 24 7643 9943  
E: enquiries@millboard.co.uk  
W: millboard.co.uk

**Drawing detail:** Cladding to decking junction

**Drawing number:** BBV-202-001

Company Registered No.06061318  
© The Millboard Company Ltd

**Date:** 09/12/2020

**Drawn By:** SH

**Scale:** NTS