



- 1 - 30mm Cladding board fixing
- 2 - Plas-Pro or Timber battens at 600mm centres
- 3 - Envello Board & Batten cladding board
- 4 - Mitred joint to be glued together, PU wood glue to be used for the core and superglue for the Lastane surface
- 5 - Plas-Pro or timber batten
- 6 - Example structural timber & sheathing or masonry wall
- 7 - Breather membrane

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens



Cladding board type: Envello Board & Batten
Orientation: Horizontal
Drawing detail: External corner detail with a mitre
Drawing number: BBH-342-001

Date: 16/12/2020
Drawn By: SH
Scale: NTS

The Millboard Company Ltd
 UK Head Office
 Castle Court
 Bodmin Road
 Coventry CV2 5DB

T: +44 24 7643 9943
 E: enquiries@millboard.co.uk
 W: millboard.co.uk

Company Registered No.06061318
 © The Millboard Company Ltd