



- 1 - Perforated Closure (behind top batten)
- 2 - Plas-Pro or Timber battens at 400mm centres
- 3 - 10mm Gap
- 4 - Plas-Pro or timber batten running up the edges to support the board ends
- 5 - Plas-Pro or Timber cross battens at 600mm centres

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens

millboard[®]

Live.Life.Outside.

Cladding board type: Envello Board & Batten

Orientation: Vertical

Drawing detail: Batten layout - Gable end

Drawing number: BBV-208-001

Date: 10/03/2021

Drawn By: SH

Scale: NTS

The Millboard Company Ltd
 UK Head Office
 Castle Court
 Bodmin Road
 Coventry CV2 5DB

T: +44 24 7643 9943
 E: enquiries@millboard.co.uk
 W: millboard.co.uk

Company Registered No.06061318
 © The Millboard Company Ltd