



- 1 - Perforated Closure
  - 2 - Plas-Pro or Timber battens at 400mm centres
  - 3 - 10mm Gap
  - 4 - Plas-Pro or timber battens at 200mm centres
- Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens



**Cladding board type:** Envello Shadow Line  
**Orientation:** Horizontal  
**Drawing detail:** Batten layout - Gable end  
**Drawing number:** SLH-008-001

**Date:** 14/12/2020  
**Drawn By:** SH  
**Scale:** NTS

The Millboard Company Ltd  
 UK Head Office  
 Castle Court  
 Bodmin Road  
 Coventry CV2 5DB

T: +44 24 7643 9943  
 E: enquiries@millboard.co.uk  
 W: millboard.co.uk

Company Registered No.06061318  
 © The Millboard Company Ltd