



- 1 - 30mm Cladding board fixing
- 2 - Plas-Pro or Timber battens at 400mm centres
- 3 - Envello Shadow Line cladding board
- 4 - Perforated closure
- 5 - External corner profile
- 6 - 20mm Accessories screw
- 7 - Plas-Pro or timber batten
- 8 - Example structural timber & sheathing or masonry wall
- 9 - Breather membrane

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens



**Cladding board type:** Envello Shadow Line  
**Orientation:** Horizontal  
**Drawing detail:** External corner profile detail  
**Drawing number:** SLH-040-002

**Date:** 14/12/2020  
**Drawn By:** SH  
**Scale:** NTS

The Millboard Company Ltd  
 UK Head Office  
 Castle Court  
 Bodmin Road  
 Coventry CV2 5DB

T: +44 24 7643 9943  
 E: enquiries@millboard.co.uk  
 W: millboard.co.uk

Company Registered No.06061318  
 © The Millboard Company Ltd