



- 1 - Plas-Pro or Timber batten at 400mm centres
- 2 - Plas-Pro or Timber cross battens at 400mm centres
- 3 - 30mm Cladding board fixing
- 4 - Envello Shadow Line Cladding Board
- 5 - Perforated closure
- 6 - Vertical Starter trim
- 7 - 20mm Accessories screw
- 8 - Boards cut edge to be painted in touch-up
- 9 - 10mm minimum
- 10 - Example flashing detail
- 11 - Example render detail
- 12 - Example structural timber & sheathing or masonry wall
- 13 - Breather membrane

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens



**Cladding board type:**  
Envello Shadow Line

**Orientation:** Vertical

The Millboard Company Ltd  
UK Head Office  
Castle Court  
Bodmin Road  
Coventry CV2 5DB

T: +44 24 7643 9943  
E: enquiries@millboard.co.uk  
W: millboard.co.uk

Company Registered No.06061318  
© The Millboard Company Ltd

**Drawing detail:** Joining render detail

**Drawing number:** SLV-109-001

**Date:** 09/03/2021

**Drawn By:** SH

**Scale:** NTS