



- 1 - Plas-Pro or Timber batten at 400mm centres
- 2 - Plas-Pro or Timber cross battens at 400mm centres
- 3 - 30mm Cladding board fixing
- 4 - Envello Shadow Line cladding board
- 5 - Mitred joint to be glued together, PU wood glue to be used for the core and superglue for the Lastane surface
- 6 - Durafix 35mm Fixings
- 7 - Perforated Closure
- 8 - Minimum 10mm gap
- 9 - Example window/door detail
- 10 - Example structural timber & sheathing or masonry wall
- 11 - Breather membrane

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens

**millboard**<sup>®</sup>

Live.Life.Outside.

**Cladding board type:**  
Envello Shadow Line

**Orientation:** Vertical

**Drawing detail:** Window/Door head junction with mitred joint

**Drawing number:** SLV-122-001

**Date:** 16/12/2020

**Drawn By:** SH

**Scale:** NTS

The Millboard Company Ltd  
UK Head Office  
Castle Court  
Bodmin Road  
Coventry CV2 5DB

T: +44 24 7643 9943  
E: enquiries@millboard.co.uk  
W: millboard.co.uk

Company Registered No.06061318  
© The Millboard Company Ltd