



- 1 - Plas-Pro or Timber batten at 400mm centres
- 2 - Plas-Pro or Timber cross battens at 400mm centres
- 3 - Envello Shadow Line cladding board
- 4 - 30mm Cladding board fixing
- 5 - Durafix 45mm fixings
- 6 - Junction between cladding boards and fascia to be sealed with silicone, the back edge of fascia will need to be finished with touch-up coating if visible
- 7 - Fascia boards, cut down to suit the reveals
- 8 - Durafix 35mm Fixings
- 9 - Junction between back of fascia boards and window to be sealed with silicone
- 10 - Example window/door detail
- 11 - Example structural timber & sheathing or masonry wall
- 12 - Breather membrane

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens



**Cladding board type:** Envello Shadow Line  
**Orientation:** Vertical  
**Drawing detail:** Window/Door jamb junction Fascia  
**Drawing number:** SLV-121-002

**Date:** 28/01/2021  
**Drawn By:** SH  
**Scale:** NTS

The Millboard Company Ltd  
 UK Head Office  
 Castle Court  
 Bodmin Road  
 Coventry CV2 5DB

T: +44 24 7643 9943  
 E: enquiries@millboard.co.uk  
 W: millboard.co.uk

Company Registered No.06061318  
 © The Millboard Company Ltd