



- 1 - 25x100mm Plas-Pro or Timber batten
- 2 - Plas-Pro or Timber battens at 400mm centres
- 3 - Perforated Closure
- 4 - Horizontal Starter Trim
- 5 - Example wall with breather membrane

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens



Cladding board type: Envello Shadow Line
Orientation: Horizontal
Drawing detail: Batten layout
Drawing number: SLH-006-001

Date: 11/12/2020
Drawn By: SH
Scale: NTS

The Millboard Company Ltd
 UK Head Office
 Castle Court
 Bodmin Road
 Coventry CV2 5DB

T: +44 24 7643 9943
 E: enquiries@millboard.co.uk
 W: millboard.co.uk

Company Registered No.06061318
 © The Millboard Company Ltd