



- 1 - Perforated Closure
- 2 - Plas-Pro or Timber battens at 600mm centres
- 3 - 10mm Gap
- 4 - Plas-Pro or timber battens at 200mm centres

Note: If treated timber battens are being used, we would recommend putting a strip of DPC, joist tape or epdm on to the front of the battens

**millboard**<sup>®</sup>

Live.Life.Outside.

**Cladding board type:** Envello Board & Batten

**Orientation:** Horizontal

**Drawing detail:** Batten layout - Gable end

**Drawing number:** BBH-308-001

**Date:** 10/03/2021

**Drawn By:** SH

**Scale:** NTS

The Millboard Company Ltd  
 UK Head Office  
 Castle Court  
 Bodmin Road  
 Coventry CV2 5DB

T: +44 24 7643 9943  
 E: enquiries@millboard.co.uk  
 W: millboard.co.uk

Company Registered No.06061318  
 © The Millboard Company Ltd